

Proxidyne Wireless Grocer Cashier Call Button System

The Wireless Grocer Cashier Call Button System allows cashiers to easily request help so that they can keep working. To request assistance, they just touch one of several labeled buttons which communicates a specific request such as “change needed” or “price check.”



- **Wireless:** Installs easily with secure bracket requiring no wires
- **Flexible:** Change announcement anytime via web UI
- **Powerful:** Select or record a different announcement and group, i.e., channel, for each button 1, 2, 3 or 4
- **Compatible:** Transmit to existing radios or smart phones
- **Trackable:** Real-time analytics with the Proxidyne Platform
- **Secure:** Uses industry-standard security
- **Range:** Up to 300,000 sq ft



Customize button's colors, graphics, backlighting and other options!



Call Button

Place a custom call button anywhere. Notify staff when a customer presses the button.

Fitting Room

Customers can press a button inside the fitting room to ask for assistance for that specific room.

Customer Service Desk

Call staff to a service desk with the press of a button that triggers a radio broadcast.

Cashier

Keep cashiers working with buttons to call for assistance such as change, price check, open another register and manager needed. Requests can be delivered to the right audience by radio, text or other medium.

Technical Specifications

Network Connectivity	Bluetooth 4.0
Power	2 AA Batteries
Battery Life	Up to 1 year
Security	AES-128 Encryption



Sample cashier button. Customize button's colors, graphics, back-lighting and other options. Use Proxidyne Platform and your radios to play custom announcements for each button press.



Sample survey button. Completely customizable. Use Proxidyne Platform to collect customer data in real time.